

Mr. Flame Fireplace “Flares” Instructions

Step 1) Lay glass door, front side down, on a clean flat surface, so that you have access to the back of the door. Be sure to protect glass by laying it on a blanket or soft surface.

Step 2) Remove the (2) screws from each flare. Flip flares over and lay carefully on each side of the glass door. They will be reattached to the same holes that they were removed from.

Step 3) Place one flare on side of glass door and line up the holes. Flare will now overlap the side of the glass door. Use the (2) screws, removed earlier, and screw into place. Repeat process with opposite side flare.

Step 4) Side flares are now properly assembled. Follow door installation instructions.

www.FireplaceDoorStore.com

GO Sales Inc.

3334 SE Teal Dr.

Gresham, OR 97080

1-877-663-7454